MOBIL TEMP INC 11871 EAST GRAND RIVER RD., BRIGHTON



INSTALLATION INSTRUCTIONS

MOBIL TEMP GAS WATER HEATERS . MODELS G 600 - G 800 SERIES

READ INSTRUCTIONS CAREFULLY BEFORE INSTALLING HEATER

- Locate outside position where heater is to be installed. (NOTE: Unit is not to be accessable from inside of trailer coach or mobile home.)
- Cut an opening 143/8" high by 127/8" wide in outer skin of trailer. Then remove insulation, exposing the inner wall of the trailer.
- Using the bottom line of the exterior opening, cut the inner wall 12 1/8" above the bottom line. Cut sides to the same width as exterior opening (12 1/8").
- Make framing to receive the heater. Framing is installed between the inner and outer walls of the trailer. Use at least 1" material top and 2 sides, being careful not to reduce the size of the opening. Fasten framing securely to the inside wall of trailer. This provides a backing to receive the screws which anchor the heater to the wall.
- Unlock fastener and remove the front exterior cover.
- Insert heater into opening. Use caulking liberally so that when the outer frame of the heater is screwed to the trailer a watertight bond is made.
- Install screws (16) in the holes provided. (Outside heater jacket frame.)
- Connect water and gas lines. Fill tank with water.
- Remove Service Manual before lighting. Manual to be placed in a safe, dry place inside of the trailer for owner's future reference.
- Follow lighting instructions attached to the inside front of heater.

CAREFULLY CHECK FOR ANY AND ALL POSSIBLE WATER OR GAS LEAKS. ALL GAS CONNECTIONS SHOULD BE CHECKED WITH SOAPY WATER APPLIED BY BRUSH.

Replace and secure the exterior panel.

NOTE . NO HOLES OR OPENINGS SHALL BE PERMITTED WHICH COULD ALLOW THE PRODUCTS OF COMBUSTION TO ENTER THE LIVING AREA.

OUTER SKIN OF TRAILER INNER WALL 1436" 12%" SCREW-FLOOR OF TRAILER OUTER SKIN OF TRAILER 12/8 -12%"-

> INNER WALL **OPENING**